

# UH36 MONO/DUAL

Wired Headset

## Quick Reference Guide



### GETTING STARTED

Unbox the contents of the headset.


### PACKAGE CONTENTS



MONO HEADSET




DUAL HEADSET




YHC20

DRAWSTRING BAG



QUICK START GUIDE



**NOTES:** You should use the included accessories as other accessories may have compatibility issues that prevent them from working properly.

# CONNECTING THE HEADSET TO A PC OR YEALINK PHONE


The following diagram will assist with connect the headset properly.

Connect the headset to a PC or compatible Yealink phone using the YHC20 USB Connector.




# CONNECTING THE HEADSET TO A SMARTPHONE OR TABLET

Connect the headset to a Tablet or Smart Phone *without* the YHC20 USB Connector.



# HEADSET CONTROLS



Button	Description
Answer/End	Press to answer or end a call.
Mute	Press to mute/unmute the microphone.
Voice Assistant	Press and hold for two seconds to activate Cortana.
Volume Up	Press to increase volume.
Volume Down	Press to decrease volume.